



HC 134 - High Cycle Vibrator - 220V - 180Hz

PARTS BREAK DOWN FOR HC134

H180	Steel Nose	BR110	Rotor Bearing
H180R	Rubber Nose	H134-5	Bearing Retainer
A2517	Snap Ring	H175-9	Snap Ring
BR106	Eccentric Bearing	12222603	Ground Screw
H134-3	Eccentric Barrel	H188	Hose Connector
H134-4	Eccentric	H134	Motor Barrel & Stator
H268	Snap Ring	H184	Rotor

Threads

LH: Left Hand
RH: Right Hand