



HC 134 - High Cycle Vibrator - 220V - 180Hz

PARTS BREAK DOWN FOR HC134

D1.75-1	Steel Nose	BR110	Rotor Bearing
D1.75-1R	Rubber Nose	H134-5	Bearing Retainer
A2517	Snap Ring	H175-9	Snap Ring
BR129	Eccentric Bearing	H188	Hose Connector
H134-3	Eccentric Barrel	H134	Motor Barrel & Stator
H134-4-B	Eccentric	H184	Rotor
H268	Snap Ring		

Threads

LH: Left Hand
RH: Right Hand