



## HC 300 - High Cycle Vibrator - 220V - 180Hz

### PARTS BREAK DOWN FOR HC250

H325	Steel Nose		H325R	Rubber Nose
H352	Eccentric Barrel		H263	Motor Barrel & Stator
H355	Eccentric		13823004	Ground Screw
H256-B	Female Driver		SP402	Snap Ring
H358	Center Connector		H269	Hose Connector
1114104	Set Screw		BR127	Eccentric Bearing
H260-B	Male Driver		BR129-B	Motor Bearing
H262	Rotor & Spacer		RS117	"O" Ring
			RS101	"O" Ring

#### Threads

LH: Left Hand  
RH: Right Hand