



## HC300 - High Cycle Vibrator - 220V - 180Hz

### PARTS BREAK DOWN FOR HC300

H325	Steel Nose		H325R	Rubber Nose
H352	Eccentric Barrel		H263	Motor Barrel & Stator
H355	Eccentric			
H256-B	Female Driver		SN-SP402	Snap Ring
H358	Center Connector		H269	Hose Connector
			BR127	Eccentric Bearing
H260-B	Male Driver		BR129-B	Motor Bearing
H262-NEW	Rotor & Spacer		RS117	"O" Ring
SN-H268	Snap Ring		RS101	"O" Ring

#### Threads

LH: Left Hand  
RH: Right Hand