



## HC200 - High Cycle Vibrator - 220V - 180Hz

### PARTS BREAK DOWN FOR HC200

D2.0-2	Steel Nose	H200	Motor Barrel & Stator
D2.0-10	Rubber Nose	H208	Hose Connector
RS109	"O" Ring/Nose	12222603	Ground Screw
H203	Eccentric Barrel	H267	Spacer
BR115	Eccentric Bearing	SN-H268	Snap Ring
H202	Eccentric	SN-D2.0-8	Snap Ring
RS110	"O" Ring	BR106	Rotor Bearing
H204	Rotor		

#### Threads

LH: Left Hand  
RH: Right Hand